

Instruction Sheet: Sugar Dispenser Decal Application (model AC2-GP)

Complete the software update BEFORE applying the new decal.



**Sample Button Panel
(Before decal is applied)**

Clean the Button Panel

1. Press and hold the **McDonald's logo** until lights on the button panel are flashing.



2. Clean the button panel with a soft cloth dampened with warm, clean, and soapy water.
3. Wipe the button panel using a soft cloth dampened with warm, clean water to remove any traces of soap or residue.
4. Wipe the button panel dry with a soft cloth.

If you have any questions or concerns while performing this procedure, please contact the SureShot Solutions Technical Assistance Center by phone (888 777-9990 or +1 902 865 9602) or email (service@sureshotsolutions.com). Find other helpful instruction sheets and videos on our website at www.sureshotsolutions.com.

Instruction Sheet:

Sugar Dispenser Decal Application (model AC2-GP)

Apply the Button Panel Decal

1. With the button panel lights still flashing, remove the plastic backing from behind the top section of the decal.

Peel away top section of plastic backing



2. Hold the sides of the decal and position it on the button panel by aligning the display cut-out on the decal, with the display on the button panel. Do NOT let the decal stick to the button panel while you are positioning it.



3. Once positioned, slowly and carefully press the decal into place around the display.
4. Working from top to bottom, slowly peel away the rest of the plastic backing while carefully pressing the remaining portion of the decal in place.

Peel away plastic backing

Press remaining decal in place from top to bottom



5. Smooth out the decal to remove any bubbles or wrinkles. Any remaining air bubbles can be worked out by smoothing the decal towards the closest edge.
6. Press and hold the **panel disable button** (●) until lights on the button panel stop flashing.

If you have any questions or concerns while performing this procedure, please contact the SureShot Solutions Technical Assistance Center by phone (888 777-9990 or +1 902 865 9602) or email (service@sureshotsolutions.com). Find other helpful instruction sheets and videos on our website at www.sureshotsolutions.com.