

- **Clean product hoppers once a month.**

Remove the hoppers from the dispenser. Remove the augers at the bottom of the hoppers. Wash the hoppers and augers thoroughly in warm soapy water. Rinse with warm clean water. Allow to air-dry completely. Reassemble. We recommend having extra hoppers so that you can put in clean, dry hoppers while the others are drying. Each time you clean the hoppers, examine the ends of the augers for wear. Replace as needed.

- **Clean product tubes.**

When cleaning the hoppers, clean and dry the tubes. Wash the tubes in warm soapy water and rinse with warm clean water. Allow to air-dry completely.

- **Clean inside the dispenser.**

After removing the hoppers during the cleaning cycle, remove any spilled product from inside the dispenser. This spilled product can interfere with the hopper properly connecting into the motor couplers at the back of the dispenser.

- **Fill the hoppers.**

Make sure product inside the hopper is always filled above the low-level line.

- **Make the perfect beverage.**

Always dispense the dairy and sugar products first and then the beverage, such as coffee, into the cup.

- **Don't forget: Ask, Ask, Tell.**

Ensure you make it perfectly.