

Instruction Sheet: Remove and Replace a Dairy Dispenser Door Gasket

Follow these instructions to remove and replace the door gasket:

1. Open the main dispenser door fully - until it stops.
2. Locate the grey plastic door gasket that surrounds the inside of the door. This gasket seals the refrigerated compartment and is held in place by hex-headed screws.
3. Lift the lip of the gasket away from the stainless steel inner door panel. There you will notice hex-headed screws that hold the gasket in place.



4. Remove all screws.
5. Remove the inner door panel from the gasket and discard the old gasket. Pay particular attention to the location of the inner door panel as it relates to the proper groove in the gasket – this will help you align the replacement gasket properly.
6. Install the inner door panel into the new door gasket.
7. Using a handheld hole punch, punch screw holes into the new gasket using the holes in the inner door panel as a guide. Make sure the screw holes in the inner door panel and the screw holes in the gasket align properly.
8. Hold the inner door panel and gasket in place and insert the hex-headed screws. Be careful not to over tighten the screws. When installed properly the door gasket will sit smoothly on the door, without being puckered or pinched.

If you have any questions or concerns while performing this procedure, please contact the SureShot Solutions Technical Assistance Center by phone at 1-888-777-9990 or e-mail at service@sureshotsolutions.com. Find other helpful instruction sheets and videos on our website: www.sureshotsolutions.com.