## McDonald's PM Card:

## IntelliShot 2.0 Refrigerated Dairy Dispenser Semi-Annual Cleaning Procedure



Semi-Annual Cleaning Every 6 Months BE95 S1

**Why** To ensure dispenser refrigerates efficiently.

**Time required** 3 minutes to prepare 15 minutes to complete

**Time of day** At close For 24-hour restaurants: during low volume periods

Hazard icons Electricity Sharp Objects/Surfaces

## **Tools and Supplies**





Philips screwdriver

Vacuum with soft brush attachment

## Semi-Annually: Condenser

1. Turn off and unplug the dispenser.





4. Reinstall the lower back panel using the screws removed in step 2 to secure the panel in place.



Remove the lower back panel by removing the screws that secure it in place. Carefully pull the back panel off of the dispenser.



5. Plug in the dispenser and turn it on.



(L)

3. Gently clean the condenser using a vacuum with a soft brush attachment. The condenser fins are very sharp and can cause cuts, even if touched gently. Do not touch the condenser fins.



Sharp Objects/Surfaces

If you have any questions or concerns while performing this procedure, please contact the SureShot Solutions Technical Assistance Center by phone at 888 777-9990 or email at service@sureshotsolutions.com. Find other helpful instruction sheets and videos on our website: www.sureshotsolutions.com.

D-19-248-8 Rev. D Page 1 of 1